



IO Zone 583 BAS Point List

Display Name	Network Visible	Read/Write	Units	Default Value	Reference Name	Object Type	Object ID	BACnet Property	Control Program
Zone Temp	TRUE	R	°F		zone_temp	AI	0	Present Value	fan_coil_unit_rev20200527.equipment
Cool Request	TRUE	R	no units		cool_request	AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Cooling Run Request	TRUE	R	no units		cl_run_for	AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Heat Request	TRUE	R	no units		heat_request	AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Heating Run Request	TRUE	R	no units		ht_run_for	AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	fan_coil_unit_rev20200527.equipment
Cooling Valve	TRUE	R/W		0	chw_valve	BO	0	Present Value	fan_coil_unit_rev20200527.equipment
Fan High Speed	TRUE	R/W		0	fan_hi	BO	0	Present Value	fan_coil_unit_rev20200527.equipment
Fan Low Speed	TRUE	R/W		0	fan_lo	BO	0	Present Value	fan_coil_unit_rev20200527.equipment
Fan Med Speed	TRUE	R/W		0	fan_med	BO	0	Present Value	fan_coil_unit_rev20200527.equipment
Heating Valve	TRUE	R/W		0	hw_valve	BO	0	Present Value	fan_coil_unit_rev20200527.equipment
Occ Status	TRUE	R			occ_status	BV	0	Present Value	fan_coil_unit_rev20200527.equipment
Override Off	TRUE	R			ovrd_off	BV	0	Present Value	fan_coil_unit_rev20200527.equipment
Override On	TRUE	R			ovrd	BV	0	Present Value	fan_coil_unit_rev20200527.equipment
Run	TRUE	R			run	BV	0	Present Value	fan_coil_unit_rev20200527.equipment
Schedule	TRUE	R/W		0	schedule	BV	0	Present Value	fan_coil_unit_rev20200527.equipment
ZS_COMM	TRUE	R			zs_comm	BV	0	Present Value	fan_coil_unit_rev20200527.equipment
ZST_FAIL	TRUE	R			zst_fail	BV	0	Present Value	fan_coil_unit_rev20200527.equipment
ZTMP_HI	TRUE	R			ztmp_hi	BV	0	Present Value	fan_coil_unit_rev20200527.equipment
ZTMP_LO	TRUE	R			ztmp_lo	BV	0	Present Value	fan_coil_unit_rev20200527.equipment
Fan Speed Status	TRUE	R			fan_run	MSV	0	Present Value	fan_coil_unit_rev20200527.equipment