



IO Zone 560 BAS Point List

Display Name	Network Visible	Read/Write	Units	Default Value	Reference Name	Object Type	Object ID	BACnet Property	Control Program
Zone Temp	TRUE	R	°F		zone_temp	AI	0	Present Value	water_source_heat_pump.equipment
Cool Request	TRUE	R	no units		cool_request	AV	0	Present Value	water_source_heat_pump.equipment
Enabled Stages	TRUE	R	no units		enabled_cmpstages	AV	0	Present Value	water_source_heat_pump.equipment
Heat Request	TRUE	R	no units		heat_request	AV	0	Present Value	water_source_heat_pump.equipment
Run Request	TRUE	R	no units		sys_run_req	AV	0	Present Value	water_source_heat_pump.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	water_source_heat_pump.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	water_source_heat_pump.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	water_source_heat_pump.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	water_source_heat_pump.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	water_source_heat_pump.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	water_source_heat_pump.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	water_source_heat_pump.equipment
Setpoint	TRUE	R/W	°F			AV	0	Present Value	water_source_heat_pump.equipment
Compressor Demand	TRUE	R			demand_compressor	BV	0	Present Value	water_source_heat_pump.equipment
Fan Demand	TRUE	R			dmd_fan	BV	0	Present Value	water_source_heat_pump.equipment
Occ Status	TRUE	R			occ_status	BV	0	Present Value	water_source_heat_pump.equipment
Override Off	TRUE	R			ovrd_off	BV	0	Present Value	water_source_heat_pump.equipment
Override On	TRUE	R			ovrd	BV	0	Present Value	water_source_heat_pump.equipment
Reversing Valve Demand	TRUE	R			demand_reversing_valve	BV	0	Present Value	water_source_heat_pump.equipment
Run	TRUE	R			run	BV	0	Present Value	water_source_heat_pump.equipment
Schedule	TRUE	R/W		0	schedule	BV	0	Present Value	water_source_heat_pump.equipment
ZS_COMM	TRUE	R			zs_comm	BV	0	Present Value	water_source_heat_pump.equipment
ZST_FAIL	TRUE	R			zst_fail	BV	0	Present Value	water_source_heat_pump.equipment
ZTMP_HI	TRUE	R			ztmp_hi	BV	0	Present Value	water_source_heat_pump.equipment
ZTMP_LO	TRUE	R			ztmp_lo	BV	0	Present Value	water_source_heat_pump.equipment
Mode	TRUE	R			mode	MSV	0	Present Value	water_source_heat_pump.equipment